

Update the AP software by using the CLI commands within the

End-User mode

- (1) Boot up the AP within the End-User (application) mode
- (2) Open a Hyper Terminal window with baud rate 115200, 8, N, 1
(username: admin password: iktpw)
- (3) wlan0-> rm art.sys (if you don't delete art.sys, the flash space will be not enough.)
- (4) Setup one external FTP server for image file transmission.

Download bootrom_v16.sys to the flash file system. For example,

wlan0-> ftp 192.168.1.xxx

Username: xxx

Password: xxx

Remote File: **5354AP1_bootrom_v16.sys**

Local File: **bootrom.sys**

download or upload: download

Getting xxx@192.168.1.100: 5354AP1_bootrom_v16.sys ->

bootrom.sys

#####

#####

#####

#####

#####

#####

#####

#####

#####

done

xxxxxxx bytes

- (5) Change to "Super-User" mode. For example,
Wlan0 -> **admin**
password: **senao**
- (6) Execute the "bootrom" command. For example,

Wlan0 -> **bootrom bootrom.sys**

Updating boot firmware with a flat binary file bootrom*.sys

This is a risky operation!

Are you sure (y/n)? **y**

- (7) Download 5354AP1_v17.sys to the flash file system. For example,

```
wlan0-> ftp 192.168.1.xxx
```

Username: xxx

Password: xxx

Remote File: **5354AP1 v17.SYS**

Local File: **apimg1**

download or upload: download

Getting xxx@192.168.1.100: 5354AP1_v17.sys -> apimg1

#####

#####

#####

#####

#####

#####

#####

#####

#####

done

xxxxxxx bytes

- (8) Remove bootrom.sys

```
rm bootrom.sys
```

- (9) Type the command **reboot** to reboot the AP.